



IP Camera Series Transcendent Series 3 Megapixel Outdoor WDR IP Cameras with up to 150' IR Range



FEATURES

- 1/3" 3.0 Megapixel Progressive Scan CMOS image sensor
- Up to 30fps live view @ 1920x1080 (2MP) / 15fps live view @ 2048x1536 (3MP)
- Fixed Iris Lens & Varifocal Lens Options
- Up to 150' IR Range
- Wide Dynamic Range (WDR)
- True Mechanical Day/Night function by ICR
- 3D-DNR Noise Reduction
- Remote Viewing via CMS, Internet Explorer, and iOS & Android Apps
- Minimal Latency with up to 10 simultaneous user connections
- On Board Motion Detection
- H.264/MJPEG Dual Streaming
- Onvif Compliance
- IP66 Weather Resistance
- 12VDC & PoE (Power over Ethernet) Operation

VITEK



Please read this manual carefully for correct use of the product.

Notes

- Please use the specified power supply to connect.
- Do not attempt to disassemble the camera; in order to prevent electric shock, do not remove screws or covers.
- There are no user-serviceable parts inside. Please contact the nearest service center as soon as possible if there is any failure.
- Avoid incorrect operation, shock vibration, heavy loads which can cause damage to the camera.
- Do not use corrosive detergent to clean body of the camera. If necessary, please use soft dry cloth to wipe dirt; for hard contamination, use neutral detergent. Any cleanser for high grade furniture is applicable.
- Avoid aiming the camera directly towards extremely bright objects, such as the sun, this may damage the image sensor.
- Please follow the instructions to install the camera.
- Do not operate it incase temperature; humidity and power supply are beyond the limited stipulations.
- Keep away from heat sources such as radiators, heat registers, stove, etc.
- Do not expose the product to the direct airflow from an air conditioner.
- We may reserve the rights to amend typographical errors, inconsistencies with the latest version, software upgrades and product improvements, interpretation and modification. These changes will be published in the latest version without special notification.
- The pictures and screenshots in this manual are only used to explain the usage of our product. The ownerships of trademarks, logos and other intellectual properties related to Microsoft, Apple and Google belong to the above-mentioned companies.
- This manual is suitable for IR weather-proof network camera. All pictures and examples used in the manual are for reference only. .

Table of Contents

1	IE Remote Access	3
1.1	LAN	3
1.1.1	Access through IP-Tool	3
1.1.2	Directly Access through IE	4
1.2	WAN	5
2	Remote Preview	6
2.1	The Remote Preview Interface	6
2.2	Record Playback	7
2.3	Snap Pictures	8
3	Remote Configuration	9
3.1	System Configuration	10
3.1.1	Basic Information	10
3.1.2	Date & Time Configuration	10
3.2	Video Configuration	10
3.2.1	Camera Configuration	11
3.2.2	Video Stream	11
3.2.3	OSD Configuration	12
3.2.4	Video Mask	12
3.2.5	ROI Configuration	13
3.3	Alarm Configuration	14
3.3.1	Motion Detection Area	14
3.3.2	Motion Detection Trigger	15
3.3.3	Motion Detection Schedule	16
3.4	Network Configuration	16
3.4.1	Port	16
3.4.2	IP Address	17
3.4.3	Server Configuration	17
3.4.4	IP Notify	18
3.4.5	DDNS Configuration	18
3.4.6	RTSP	19
3.4.7	UPnP	20
3.4.8	Mail Setting	20
3.4.9	FTP	21
3.5	Advanced Configuration	21
3.5.1	User Configuration	21
3.5.2	Security Configuration	23
3.5.3	Configure Backup & Restore	23
3.5.4	Reboot Device	24
3.5.5	Upgrade	24
4	Q & A	25

1 IE Remote Access


IP-CAM can be connected through LAN or WAN. Take IE browser (6.0) for example. The details are as follows:

1.1 LAN


In LAN, there are two ways to access IP-CAM: 1. Access through IP-Tool; 2. directly access through IE browser.

1.1.1 Access through IP-Tool

- ① Make sure the PC and IP-CAM are connected to the LAN and the IP-Tool is installed in the PC
- ② Double click the IP-Tool icon on the desktop to run this software as shown below:



- ③ Modify the IP address. The default IP address of this camera is 192.168.226.201. Click the information of the camera listed in the above table to show the network information on the right hand. Modify the IP address and gateway of the camera and make sure its network address is in the same local network segment as the computers. Modify the IP address of your device according to the practical situation.




For example, the IP address of your computer is 192.168.13.4. So the IP address of the camera shall be changed to 192.168.13.X. After modification, please input the password of the administrator and click “Modify” button to modify the setting.



The default password of the administrator is “**123456**”.

④ Double click the IP address and then the system will pop up IE browser to connect IP-CAM. IE browser will automatically download the Active X control. After downloading, a login window will pop up as shown below.



Input the username and password to log in.



The default username is “**admin**”; the default password is “**123456**”.

1.1.2 Directly Access through IE

The default network settings are as shown below:

IP address: 192.168.226.201

Subnet Mask: **255.255.255.0**

Gateway: 192.168.226.1


HTTP: **80**

Data port: **9008**


You may use the above default settings when you log in the camera for the first time.

① Manually set the IP address of the PC, the network segment should be the same as the default settings of the IP camera. Open the network and share center. Click “Local Area Connection” to pop up the following window.

Transcendent Series: IP Cameras



Select “Property” and then select internet protocol according to the actual situation (for example: IPV4). Next, click “Property” button to set the network of the PC.



- ② Open [an](#) IE browser and input the default address of IP-CAM and confirm. The IE browser will download Active X control automatically.
- ③ After downloading Active X control, the login dialog box will pop up.
- ④ Input the default username and password and then enter to view.

1.2 WAN

To access the camera via a router or virtual server:

- ① Make sure the camera is connected via LAN and then log in the camera via LAN and go to the Config→Network Config→Port menu to set up the port number.
- ② Go to Config →Network Config→IP Address menu to modify the IP address.
- ③ Go to the router’s management interface through IE browser to forward the IP

address and port of the camera in the “Virtual Server”.

Network basic config

HTTP Port:

Data Port:

RTSP Port:

Port Setup

IP Config

Obtain an IP address automatically

Use the following IP address

IP Address:

Subnet Mask: Gateway:

Obtain DNS server address automatically

Use the following DNS server

Preferred DNS server: Alternate DNS server:

IP Setup


Port Range					
Application	Start	End	Protocol	IP Address	Enabl
1	9008	9008	Both	192.168.6.6	<input checked="" type="checkbox"/>
2	80	81	Both	192.168.6.6	<input checked="" type="checkbox"/>
3	10000	10001	Both	192.168.6.166	<input type="checkbox"/>
4	21000	21001	Both	192.168.6.156	<input type="checkbox"/>
5	7777	7778	Both	192.168.6.206	<input type="checkbox"/>
6	1029	1030	Both	192.168.6.207	<input type="checkbox"/>

Router Setup

- ④ Open the IE browser and input its WAN IP and http port to access.

2 Remote Preview

2.1 The Remote Preview Interface



Remote Preview

1	Motion Detection	4	Zoom in	7	Start recording
2	Fix size	5	Zoom out	8	Playback
3	Actual size	6	Full screen	9	Snap

- When motion detection alarm is triggered, the people icon turns red.


Right click to pop up a pull-down list as shown below:

Stream: Three streams are optional.

Turn off the live: Click this item to close present live preview.



Full screen: The live preview picture will be full-screen display. Double click or right click mouse to return to the previous interface.


Online user: Display the current user connecting to the device.



System information: Display the device information: device name, firmware version, software build date, kernel version and hardware version.

2.2 Record Playback


Before you play the recorded files, please make sure you have recording. Click  button to start recording and again to stop recording. Then click  button to pop up a video player. Double click the recorded file to play the video as shown below.



1	Play	5	Next frame	9	Zoom out
2	Pause	6	The previous file	10	Full screen
3	Stop	7	The next file	11	Path
4	Forward	8	Zoom in	12	Volume


2.3 Snap Pictures

Select the picture number and then click “Snap”  icon as shown below.



Single Snap

User can snap multiple pictures. Select the picture number from Frame pull down list box, such as 2, and check “Title” and “Time” to show capture title and time on the snap pictures simultaneously.



Multi-picture Snap

Click “Browse” to set saving path. Click “Save” to save pictures to HDD on the computer; Click “Printer setup” to set the printer and print the snap pictures; drag the scroll bar to view all snapped pictures.

3 Remote Configuration

Functions of remote configuration include: System Configuration, Video Configuration, Alarm Configuration, Network Configuration and Advanced Configuration. You should

first select the menu on the left, and then set the relative parameters.

3.1 System Configuration


The “System configuration” includes two submenus: Basic Information and Date & Time.

3.1.1 Basic Information

In the basic information interface, user can set up the device name and also can check the relative information of the server.

Setting steps:

1. Clicking the “Config” icon [bring up](#) the menu list.
2. Clicking the “Basic Information” will pop up a window as shown below.
3. Input the name of the device in the “Device name” text box.
4. Press the “Save” button to save the settings.




Software Version	3.4.1 beta4	Software Build Date	2014-8-25 (YYYY-MM-DD)
Kernel Version	20140819	Hardware Version	1.3
MAC	00:18:AE:39:97:4A	Onvif Version	2.3
Device name	name	Maximum number of	10

3.1.2 Date & Time Configuration

Setting steps:

1. Go to “System Configuration” → “Date & Time”.



Time Zone: GMT-08 (Las Vegas, San Francisco, Vancouver)

DST Enable

Timing mode

Manual

Set Time: 7/17/2015 12:26:28 PM PC time

NTP

NTP Server: time.windows.com

2. Set time zone.
3. Enable DST mode as required.
4. Set time. You may set time manually or enable NTP.

3.2 Video Configuration

Camera Configuration includes five submenus: Camera Configuration, Video Stream,

OSD Config, Video Mask and ROI Config.

3.2.1 Camera Configuration

Setting steps:


1. Go to “Video Configuration” → “Camera” interface as shown below.



2. You may adjust frequency, brightness, contrast, hue and saturation of the picture.
3. Select white balance mode.
4. Wide dynamic, sharpen and denoise are adjustable.
5. You can also set the image mirror and image flip function.
6. Press the “Save” button to save the settings.

3.2.2 Video Stream

Go to “Video configuration” → “Video Stream” to see an interface as shown below.



Three video streams can be adjustable.

Resolution: The higher the resolution, the clearer the image is.

Frame rate: The higher the frame rate, the more fluency the video is. However, more storage room will be used.

Bitrate type: CBR and VBR. CBR means that no matter how much the video changes, the compression bitrate keeps constant. This will not only facilitate the image quality better in a constant bitrate but also help to calculate the capacity of the recording. VBR means that the compression bitrate can be adjustable according to the changes in the video. This will help to optimize the network bandwidth.

Video Quality: When VBR is selected, you need to choose image quality. The higher

the image quality, the more bitrate will be required.

Bitrate: Please choose it according to the actual network situation.

I Frame interval: It is recommended to use the default value. If the value is too high, the read speed of the group of pictures will slow resulting in quality loss of video.

Video encoding profile: Baseline, main and high profile are options. Baseline profile is mainly used in interactive application with low complexity and delay. Main/high profile is mainly used for higher coding requirement.


Alarm picture size: Please select it according to the actual situation.

Video encode slice split: If enabled, you may get more fluency in image even though using a low-performance PC.

3.2.3 OSD Configuration

1. Go to “Video Config” → “OSD Config” menu to display the interface as shown below.


You may set time stamp, device name and custom OSD here. Drag the time stamp and custom OSD to set their position. Then press the “Save” button to save the settings.



- 2.


3.2.4 Video Mask

You can set up to 4 masked areas.



To set up video mask

1. Enable video mask and select mask color.
2. Click “Draw” button and then drag the mouse to draw the video mask area.
3. Click “Save” button to save the settings.
4. Return to live view to see the following picture.




Clear the video mask:

Go to video mask menu and then click “Clear” button to delete the current video mask area.

3.2.5 ROI Configuration

To set up ROI

1. Go to Config→ROI Config menu.



2. Check “Enable” and then click “Draw” button.
3. Drag the mouse to set the ROI area.
4. Set the level.
5. Click “Save” button to save the settings.

You will see the selected ROI area is clearer than other areas especially in low bitrate condition.




3.3 Alarm Configuration

Alarm configuration includes three submenus: Motion Detection Area, Motion Detection Trigger and Motion Detection Schedule.


3.3.1 Motion Detection Area

1. Go to “Alarm configuration” → “Motion Detection Area” to see an interface as shown below.
2. Move the “Sensitivity” scroll bar to set up the motion trace sensitivity.
3. Check “Add”, press the “Ctrl” button and move mouse to select the motion detection area; Select “Erase” and move the mouse to clear all motion detection area.
4. Press the “Save” button to save the settings.



3.3.2 Motion Detection Trigger

1. Go to “Alarm Configuration” → “Motion Detection Trigger” to display an interface as shown below.



2. Check “Enable alarm” check box. Then all functions under this interface will be activated.

3. Trigger Email: Check “Attach picture” and select email addresses in the “email address” text box (Email address shall be set first in the Mail config interface). Then the triggered snap pictures will be sent to those addresses. User can also define the subject and content of the email.

4. Trigger FTP: Check “Uploading picture”. The triggered snap pictures will be sent to the FTP server address.

Note: Please refer to FTP configuration chapter for more details.

5. Press the “Save” button to save the settings.

3.3.3 Motion Detection Schedule

Go to “Alarm configuration” → “Motion Detection schedule” interface as shown below.

Week schedule

User can set the alarm time from Sunday through Saturday for alarm everyday in one week.

Note: 0 ~ 24 are the hours in that day. Click on the pane to set the alarm hours. Green means selected area. Blank means unselected area.

Add: Add a schedule for a particular day.

Erase: Delete schedule.

Holiday schedule

User could set alarm time for a certain time of a special day, such as a holiday.

1. Select a date a “Date” and click “Add” button to add that date to the list box on the right side and then move the scroll bar to set the schedule of that day.

2. Select a date in the list box on the right side, and press “Erase” to remove the schedule on that day.

Press the “Save” button to save the settings.

Note: Holiday schedule has priority to Week schedule.


3.4 Network Configuration

Network configuration includes 9 submenus: Port, IP Address, Server Configuration, IP Notify, DDNS Config, RTSP, UPnP, Mail Setting and FTP.

3.4.1 Port

1. Go to “Network config” → “Port” to see the interface as shown below.

Transcendent Series: IP Cameras




Network basic config

HTTP Port	<input type="text" value="88"/>
Data Port	<input type="text" value="9008"/>
RTSP Port	<input type="text" value="554"/>

2. Input port number for web access in the “HTTP Port” textbox.
3. Input the port number for audio & video transmission in the “Data Port” textbox.

3.4.2 IP Address

1. Go to “Network Configuration”→ “IP Address” to see the interface shown below.
2. There are two options for IP setup: obtain an IP address automatically by DHCP protocol and use the following IP address. You may choose one of the options as required.
3. Use the following IP address: display the IP address, subnet mask, gateway and DNS of the device.



IP Config

Obtain an IP address automatically
 Use the following IP address

IP Address	<input type="text" value="192 . 168 . 12 . 206"/>		
Subnet Mask	<input type="text" value="255 . 255 . 255 . 0"/>	Gateway	<input type="text" value="192 . 168 . 12 . 1"/>

Obtain DNS server address automatically
 Use the following DNS server

Preferred DNS server:	<input type="text" value="192 . 168 . 226 . 1"/>	Alternate DNS server:	<input type="text" value="8 . 8 . 8 . 8"/>
-----------------------	--	-----------------------	--

PPPoE Config

PPPoE

User Name	<input type="text"/>	Password	<input type="text"/>
-----------	----------------------	----------	----------------------

4. PPPoE: User needs to manual input the user name and password for dial-up internet. First, log in web client and then enter user name and password of PPPoE, save the setting and exit. Second, set up IP address change notice. Third, connect with Modem. The device will dial up internet automatically.
5. Press the “Save” button to save the settings.

3.4.3 Server Configuration

Go to “Network Configuration”→ “Server Config”.

3.

1. Check “Do you want IP Camera to connect Server”.
2. Check the IP address and port of the transfer media server in the CMS/NVMS. Then enable the auto report in the CMS/NVMS when adding a new device. Next, self-define the device ID and input the remaining information of the device in the CMS/NVMS.
3. Input the above-mentioned server IP, server port and device ID in the relevant boxes.
4. Click “Save” button to save the settings.

3.4.4 IP Notify

1. Go to “Network Configuration”→ “IP Notify” to see a tab as shown below.
2. If the “Enable notifying change of IP” is selected, when the IP address of the device is changed, a new IP address will be sent to the appointed mailbox automatically; if “FTP” is selected, when the IP address of the device is changed, a new IP address will be sent to the FTP server.

3.4.5 DDNS Configuration

1. Go to “Network Configuration”→ “DDNS Configuration” tab as shown below.

2. Apply for a domain name. Take www. dvr dydns.com for example. Input [www. dvr dydns.com](http://www.dvr dydns.com) in the WEB address bar to visit the website. Then click “Registration” button to register as shown below.

NEW USER REGISTRATION

USER NAME	<input type="text" value="xxxx"/>
PASSWORD	<input type="password" value="••••••"/>
PASSWORD CONFIRM	<input type="password" value="••••••"/>
FIRST NAME	<input type="text" value="xxx"/>
LAST NAME	<input type="text" value="xxx"/>
SECURITY QUESTION	My first phone number.
ANSWER	<input type="text" value="xxxxxxxx"/>
CONFIRM YOU'RE HUMAN	 New Captcha <input type="text"/> Enter the text you see above

Create domain name.

You must create a domain name to continue.

Domain name must start with (a-z, 0-9). Cannot end or start, but may contain a hyphen and is not case-sensitive.

After you successfully request your domain name, you will see your domain in the list.

Search by Domain.

Click a name to edit your domain settings.

NAME	STATUS	DOMAIN
654321ABC		654321abc.dvrddns.com

Last Update: *Not yet updated* IP Address: 210.21.229.138

[Click here to add/delete domain names!](#)

3. Select the server type and then input the username, password and domain name you apply for in the DDNS configuration interface.

4. Click “Save” button to save the settings.

3.4.6 RTSP

4. Go to “Network Configuration” → “RTSP” interface as shown below.

RTSP

Enable RTSP server

RTSP Port


RTSP Address

Enable anonymous viewer login (no user name or password required)

5. 1. Select “Enable RTSP server”.
2. RTSP Port: Access Port of the streaming media. The default number is 554.
3. RTSP Address: The RTSP address you need to input in the media player.
4. You can also choose to enable anonymous viewer login.

3.4.7 UPnP

Go to “Network Configuration” → “UPnP” interface as shown below. Select “Enable UPnP” and then input friendly name.



Then double click “Network” icon on the desktop of the PC to see an icon with the friendly name and IP address of the camera. You may quickly access the device by double clicking this icon.

3.4.8 Mail Setting

Go to “Network Configuration” → “Mail Setting” interface.



1. From Email: Sender’s e-mail address.
2. User name and password: Sender’s user name and password.
3. Server address: SMTP name of sender.
4. Select the secure connection type at the Secure Connection dropdown list according to user’ actual needs.
5. Email address list: Add email address into the list.
6. Email address: Receiver’s e-mail address.
7. After all parameters are setup, you can click “Test your account settings”. If email is sent successful, a “Test Successful” window will pop up, if not, you can try other email addresses or check the setting.

Notice: If you change the static IP into PPPoE and select mailbox, there will be an

e-mail sent to your mail box for notifying a new IP address.

3.4.9 FTP

Go to Network Configuration→FTP interface as shown below.

Server name	Server address	Port ...	User Name	Upload path:

1. Add: Click Add button to input FTP server’s server name, address, port number, user name, password and upload path. Then click OK to confirm the setting.
2. Modify: Click this button to change the information of the FTP server.
3. Delete: Select a FTP account and click this button to delete this account.
4. Test: Select a FTP account and click this button to test its validity.

Please refer to the following table for parameters and instructions of FTP configuration.

<i>Parameter</i>	<i>Meaning</i>
Server name	The name of the FTP server
Server address	The address of the FTP server
Port	The port number of the FTP server
User name	The user name of the FTP server
Password	The password of the FTP server
Path	The save path for FTP files

3.5 Advanced Configuration


Advanced configuration includes four submenus: User Configuration, Security Configuration, Configure Backup & Restore, Reboot and Upgrade.

3.5.1 User Configuration


Go to “User Configuration” interface.

Add user:

1. Clicking “Add” button pops up “Add User” dialog box.



User Configuration




Add User

Note: After binding physical address to the IP-CAM, you can access the device on this PC only. If the MAC address is “00:00:00:00:00:00”, it means that it can be connected to any computers.

2. Input user name in “User Name” textbox (only letters).
3. Input characters in “Password” and “Confirm Password” textbox (letters or numbers).
4. Input the MAC address of the PC in “Binding MAC address” textbox.
5. Click “OK” button and then the new added user will display in the user list.

Modify user:

1. Select the user you want to modify password and physical address in the user configuration list box.
2. Clicking “Modify” button will pop up “Modify user” dialog box as shown below.



Modify User

3. Input original password of this user in the “Password” text box.
4. Input new password in the “New password” and “Confirmation” text box.
5. Input computer’s physical address which is used to access the server in the “User PC MAC” text box.
6. Click “OK” button to modify password and binding MAC address successfully.

Delete user:

1. Select the user you want to delete in the user configuration list box.
2. Click “Delete” button to pop up a confirm dialog box. Then click “OK” to delete the user.


Note: The default super administrator cannot be deleted.

Parameter	Meaning
-----------	---------

User Name	User name to operate the logon client end
User Type	Type of users, normal user, advanced user and super administrator
Binding MAC address	The MAC addresses of user access the server which should be set up according to actual MAC address of server.
Password	Password to log in the client terminal
Confirm Password	Password to log in the client terminal

3.5.2 Security Configuration

- Go to Advanced Configuration→Security Configuration to see a tab shown below.
 - Check “Enable IP address” check box, select “Deny the following IP address” input IP address in the IP address list box and click “Add” button. Then this IP address will display in the list box; the operation step of “Allow the following IP address” is the same as that of “Deny the following IP address”.
 - Select the IP address you want to delete from the IP address list box and click “Delete” button to delete that IP address.
 - Check “Enable MAC address” check box, select “Deny the following IP address”, input MAC address in the MAC address list box and click “Add” button. Then this MAC address will display in the list box; the operation step of “Allow the following MAC address” is the same as that of “Deny the following IP address”.
- Select the MAC address you want to delete from the MAC address list box and click “Delete” button to delete that MAC address.
- Click “Save” button to save the above setting.



3.5.3 Configure Backup & Restore

Go to Advanced configuration→Configure Backup & Restore Interface.

- Import & Export Configuration:**

- Click “Browse” to select save path for import or export information on PC.
- You can import or export all setting information, but those two settings “User

Configuration” and “Network Configuration” are optional .

The screenshot shows a web interface with three sections:

- Import setting:** A text input field for 'Path' with a 'Browse' button to its right. Below it is a dropdown menu labeled 'All configuration exception for' with a checked checkbox for 'User Config' and an unchecked checkbox for 'Network Config'. A 'Import setting' button is centered below these options.
- Export setting:** A single 'Export setting' button centered in the section.
- Default setting:** A single 'Load Default' button centered in the section.

- **Default Configuration**

Click “Load default” button to restore all system settings to the default status.

3.5.4 Reboot Device

Go to Advanced configuration—Reboot device to see an interface as shown below. Click “Reboot device” button to reboot the device.

The screenshot shows a simple interface with a dark header labeled 'Reboot' and a single 'Reboot' button centered below it.

3.5.5 Upgrade

Go to Advanced Configuration—Upgrade interface as shown below.

The screenshot shows a web interface with a dark header labeled 'Upgrade'. Below it is a text input field for 'Path' with a 'Browse' button to its right. A 'Update server firmware' button is centered below the input field.

1. Click “Browse” button to select the saved path of the upgrade file.
2. Click “Upgrade server firmware” button to start upgrading the application program.
3. The device will restart automatically. After you successfully update the software, click “OK” button to close browser and then re-open browser to connect IP-CAM.

Notice: Do not shut down the PC or close the IP-CAM during upgrade.

4 Q & A

Q: How to find my password if I forget it?

A : Reset the device to the default factory settings by IP-Tool.

Default IP: 192.168.226.201

User name: admin

Password: 123456

Q : Fail to connect devices through IE browser, why?

A: Network is not connected. Please check the connection and make sure it is connected.

B: IP is not available. Reset the valid IP.

C: Web port number has been revised: contact administrator to get the correct port number.

D: Exclude the above reasons. Recover default setting by IP-Tool.

Note: Default IP: 192.168.226.201, mask number: 255.255.255.0


Q : IP tool cannot search devices, why?

A : It may be caused by the anti-virus software in your computer. Please turn off and try to search device again.

Q : IE cannot download ActiveX control?



A. IE browser blocks ActiveX. Please do setup following below.

① Open IE browser. Click Tools-----Internet Options....



② Select Security-----Custom Level....

③ Enable all the sub options under "ActiveX controls and plug-ins".



④ Then click OK to finish setup.

B. Other plug-ins or anti-virus blocks ActiveX. Please uninstall or close them.

Q : No sound can be heard, why?

A : Audio input device is not connected. Please connect and try again.

B: Audio function is not enabled on the corresponding channel. Please check AUDIO item to enable this function.

Detailed Specifications	VTC-TNB42R3F	VTC-TNB36R3V
Image Sensor	1/3" CMOS (GM8139 + Aptina0330)	
Image Size	3 MegaPixel 2048x1536	
Electronic Shutter	1/25s~ 1/100000s	
Min. Illumination	0 Lux (IR LED ON)	
Lens	3.6mm Fixed	2.8~12mm (Vari-Focal)
IR LEDs	42	36
IR Distance	150'	120'
Compression	H.264/MJPEG	
Resolution	3 MP (2048x1536) / 1080P (1920x1080) / 720P (1280x720) / D1/CIF (480x240)	
Multi-Stream	3 MP @ 1~15fps / 1920x1080, 1280x720, D1, CIF, 480x240 @ 1~30fps	
Bitrate	64 kbps ~ 8 Mbps	
Encode Mode	VBR / CBR	
Quality	Five Level adjustable (VBR) / Random set (CBR)	
Image Setting	Saturation, Brightness, Contrast, WDR, Noise reduction	
ROI	Max 8 detailed areas can be viewed	
Network	RJ45	
Remote Viewing	CMS / Web Browser / Mobile (iOS/Android)	
Online Connection	10 online user max	
Protocol	TCP/IP, UDP, DHCP, NTP, RTSP, HTTP, PPPoE, DDNS, SMTP, FTP	
Connection Protocol	ONVIF, GB-T/28181-2011	
Smart Alarm	Motion Alarm	
Day/Night	ICR	
Weather Resistance	IP66	
Power supply	12VDC / PoE	
Working Environment	-4~122 / 10%~90% Humidity	
Weight	20.81 oz. / 1.30 lbs. / 590g	21.16 oz. / 1.32 lbs. / 600g
Dimensions	3.43 x 8.62" (87mm x 219mm) Dia x L	

Detailed Specifications	VTD-TND30R3V
Image Sensor	1/3" CMOS (GM8139 + Aptina0330)
Image Size	3 MegaPixel 2048x1536
Electronic Shutter	1/25s~ 1/100000s
Min. Illumination	0 Lux (IR LED ON)
Lens	2.8~12mm (Vari-Focal)
IR LEDs	30
IR Distance	100'
Compression	H.264/MJPEG
Resolution	3 MP (2048x1536) / 1080P (1920x1080) / 720P (1280x720) / D1/CIF (480x240)
Multi-Stream	3 MP @ 1~15fps / 1920x1080, 1280x720, D1, CIF, 480x240 @ 1~30fps
Bitrate	64 kbps ~ 8 Mbps
Encode Mode	VBR / CBR
Quality	Five Level adjustable (VBR) / Random set (CBR)
Image Setting	Saturation, Brightness, Contrast, WDR, Noise reduction
ROI	Max 8 detailed areas can be viewed
Network	RJ45
Remote Viewing	CMS / Web Browser / Mobile (iOS/Android)
Online Connection	10 online user max
Protocol	TCP/IP, UDP, DHCP, NTP, RTSP, HTTP, PPPoE, DDNS, SMTP, FTP
Connection Protocol	ONVIF, GB-T/28181-2011
Smart Alarm	Motion Alarm
Day/Night	ICR
Weather Resistance	IP66
Power supply	12VDC / PoE
Working Environment	-4~122 / 10%~90% Humidity
Weight	34.22 oz. / 2.14 lbs. / 970g
Dimensions	3.10" x 3.58" x 5.70" (78.7 × 90.9 × 144.7mm) H x W x Dia

Detailed Specifications	VTC-TNT30R3F	VTC-TNT30R3V
Image Sensor	1/3" CMOS (GM8139 + Aptina0330)	
Image Size	3 MegaPixel 2048x1536	
Electronic Shutter	1/25s~ 1/100000s	
Min. Illumination	0 Lux (IR LED ON)	
Lens	3.6mm Fixed	2.8~12mm (Vari-Focal)
IR LEDs	30	30
IR Distance	100'	100'
Compression	H.264/MJPEG	
Resolution	3 MP (2048x1536) / 1080P (1920x1080) / 720P (1280x720) / D1/CIF (480x240)	
Multi-Stream	3 MP @ 1~15fps / 1920x1080, 1280x720, D1, CIF, 480x240 @ 1~30fps	
Bitrate	64 kbps ~ 8 Mbps	
Encode Mode	VBR / CBR	
Quality	Five Level adjustable (VBR) / Random set (CBR)	
Image Setting	Saturation, Brightness, Contrast, WDR, Noise reduction	
ROI	Max 8 detailed areas can be viewed	
Network	RJ45	
Remote Viewing	CMS / Web Browser / Mobile (iOS/Android)	
Online Connection	10 online user max	
Protocol	TCP/IP, UDP, DHCP, NTP, RTSP, HTTP, PPPoE, DDNS, SMTP, FTP	
Connection Protocol	ONVIF, GB-T/28181-2011	
Smart Alarm	Motion Alarm	
Day/Night	ICR	
Weather Resistance	IP66	
Power supply	12VDC / PoE	
Working Environment	-4~122 / 10%~90% Humidity	
Weight	26.10 oz. / 1.63 lbs. / 740g	26.46 oz. / 1.65 lbs. / 750g
Dimensions	3.43" x 4.25" (87 x 108mm) Dia x H	4.07" x 4.33" (130.3 x 110mm) Dia x H



**OTHER PRODUCTS
FROM VITEK**



VT-TNR NVR SERIES

Transcend 8/16 Channel Real Time Network Video Recorders with PoE

- 8 or 16 Channel Stand-alone Real-time IP Network Video Recorder
- Full 3 Megapixel Real-time recording 240fps (VT-TNR814) or 480fps (VT-TNR1628) with 120fps playback
- HDMI & VGA Video Outputs
- H.264 Compression Method
- Plug and Play & Auto configuration for many leading ONVIF compliant IP Camera models
- Alarm In/Out (VT-TNR1628 only)
- Internal 4-Port PoE (VT-TNR814) or 8-Port PoE (VT-TNR1628) Switch
- 1 Gigabit LAN Port
- Pentaplex: Live Display / Record / Playback / Backup / Remote Access
- Network Based PTZ Control
- Applications for iOS & Android
- Remote Viewing over the Internet via Web Browser or LAN
- VT-TNR814: 1 Internal SATA2/SATA3 HDD Slot supporting up to 4TB (1 x 4TB HDD) or VT-TNR1628: 2 Internal SATA2/SATA3 HDD Slots supporting up to 8TB (2 x 4TB HDD) Internal Storage
- Mac OS® Client & CMS Central Management Software Included
- Supports both Dynamic and Static IP Addresses
- Web-based remote configuration
- Control locally via Front Panel Controls, USB Mouse, or IR Remote control

LIMITED PRODUCT WARRANTY

VITEK products carry a three (3) year limited warranty. VITEK warrants to the purchaser that products manufactured by VITEK are free of any rightful claim of infringement or the like, and when used in the manner intended, will be free of defects in materials and workmanship for a period of three (3) years, or as otherwise stated above, from the date of purchase by the end user. This warranty is nontransferable and extends only to the original buyer or end user customer of a VITEK Authorized Reseller.

The product must have been used only for its intended purpose, and not been subjected to damage by misuse, willful or accidental damage, caused by excessive voltage or lightning.

The product must not have been tampered with in any way or the guarantee will be considered null and void.

This guarantee does not affect your statutory rights.

Contact your local VITEK Reseller should servicing become necessary.

VITEK makes no warranty or guarantee whatsoever with respect to products sold or purchased through unauthorized sales channels. Warranty support is available only if product is purchased through a VITEK Authorized Reseller.

CLASS A DIGITAL DEVICE (INDUSTRIAL & COMMERCIAL ENVIRONMENT)

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to CE and FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.



28492 CONSTELLATION ROAD VALENCIA, CA 91355
WWW.VITEKCCTV.COM

Version 1.0
July 2015